

KIT #1014146 (SK)

HEARTTHROB EXHAUST SYSTEMS ARE MANUFACTURED BY HEARTTHROB EXHAUST--LITCHFIELD, MN
1983-1986 GM ¾, 1 ton PICKUP, Blazer Suburban, Carryall, SMALL BLOCK V-8 (305-400)

NOTE: THE CATALYTIC CONVERTERS ARE NOT SUPPLIED WITH THIS EXHAUST SYSTEM. This item is not legal for use on vehicles originally equipped with a catalytic converter, not legal for sale in California.

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL THIS EXHAUST PRODUCT AT HOME, BE WARNED THAT PLEASURE CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE WHILE THE INSTALLATION PROCEEDS.

HARDWARE KIT:

- | | |
|----------------------------|---|
| 4) LB7 HANGERS | 1) #16546 LEFT MANIFOLD PIPE |
| 4) SNAPPER GROMMETS | 1) #8141461 RIGHT MANIFOLD PIPE |
| 4) 5/16" X 1-1/2" BOLTS | 2) #15527 LEFT & RIGHT FRONT EXTENSION PIPE |
| 6) 5/16" NUTS | 2) SINGLE OFFSET MUFFLERS st48111 |
| 2) EG110 GASKETS | 2) TAIL PIPE EXTENSIONS #8805 |
| 10) 2-1/4" CLAMPS | 1) #8807L LEFT TAIL PIPE |
| 2) F3214 FLANGES | 1) #8806R RIGHT TAIL PIPE |
| 2) 5/16" X 1" BOLTS | |
| 2) FENDER WASHERS (33219) | |
| 2) 5/16" LOCK WASHERS | |
| 2) BR92073 SWINGER HANGERS | |

HANGER CONSISTS OF AN 'L' STRAP CONNECTED TO THE FRAME WITH A 5/16" BOLT, WASHER, SNAPPER GROMMET, AND NUT.

LIMITATION OF LIABILITY-DISCLAIMERS: THE REGULATION OF EMISSIONS PRODUCTION, NOISE LEVELS AND SAFETY STANDARDS IS UNDERTAKEN BY THE FEDERAL GOVERNMENT, EACH OF THE FIFTY STATE LEGISLATURES, AND BY MANY LOCAL MUNICIPALITIES, TOWNS AND COUNTIES.

THE MANUFACTURER MAKES NO WARRANTIES OF MERCHANTABILITY, OF FITNESS FOR A PARTICULAR PURPOSE, OR THAT ITS PRODUCTS ARE APPROVED FOR GENERAL USE, OR THAT ITS PRODUCTS COMPLY WITH LAWS, REGULATIONS OR ORDINANCES IN THE STATES WHERE THEY MAY BE SOLD TO THE ULTIMATE PURCHASER, THE CONSUMER.

THE ENTIRE RISK AS TO THE CONFORMITY OF THIS PRODUCT IN ANY SUCH STATE AND AS TO REPAIR, SHOULD THE PRODUCT PROVE TO BE DEFECTIVE OR NON-CONFORMING, IS ON THE RETAIL PURCHASER, THE BUYER, THE ULTIMATE CONSUMER, OF SUCH PRODUCT AND IT IS NOT UPON THE SELLER, DISTRIBUTOR, OR MANUFACTURER.

IN THIS CONNECTION, THE RETAIL PURCHASER, THE BUYER, THE ULTIMATE CONSUMER ASSUMES THE BURDEN OF THE ENTIRE COST OF ANY AND ALL NECESSARY SERVICE, ALTERATIONS AND OR REPAIR.

THE FOREGOING STATEMENT LIMITS THE LIABILITY OF THE MANUFACTURER.

CALIFORNIA VEHICLE CODE SECTION 27156 PROHIBITS THE ADVERTISING, OFFERING FOR SALE, OR INSTALLATION OF ANY DEVICE WHICH MODIFIES A VEHICLE'S EMISSION CONTROL SYSTEM. THIS PRODUCT IS THEREFORE NOT LEGAL FOR SALE OR USE IN CALIFORNIA ON VEHICLES EQUIPPED WITH CATALYTIC CONVERTERS.

KIT #1014146 (SK)

INSTALLATION INSTRUCTIONS:

NOTE: DO NOT TIGHTEN ANY CLAMPS OR NUTS UNTIL THE LAST STEP!!

- 1) REMOVE THE OLD EXHAUST SYSTEM. SAVE THE OLD SLEEVES (IF NECESSARY) FROM THE ORIGINAL FRONT PIPES. REMOVE THE OLD HANGERS.
- 2) INSTALL THE LEFT (#16546--85 DEG. BEND) AND RIGHT (#8141461—2 BENDS) MANIFOLD PIPES USING THE NEW GASKETS AND INCLUDED FLANGES, AND THE OLD SLEEVES IF NECESSARY. TIGHTEN ONLY ENOUGH TO HOLD IN PLACE.
- 3) INSTALL THE LEFT AND RIGHT FRONT EXTENSION PIPES TO THE MANIFOLD PIPES USING 2-1/4" CLAMPS.
NOTE: FOR VEHICLES REQUIRING CATALYTIC CONVERTERS TO MEET EPA GUIDELINES, CONVERTER PART # 73-7774 OR EQUIVALENT SHOULD BE INSTALLED ON THE MANIFOLD PIPES. SEE DRAWING. CONVERTERS ARE NOT INCLUDED IN THIS KIT.
- 4) INSTALL THE MUFFLERS ONTO THE FRONT EXTENSION PIPES USING 2-1/4" CLAMPS. (THOSE WITH GLASS PACKS, THE EXHAUST SHOULD FLOW OVER THE LOUVERS AND NOT DIRECTLY INTO THEM FOR PROPER SOUND). ROTATE THE FRONT EXTENSION PIPES TO CLEAR THE TRANSFER CASE, DRIVESHAFT, AND FRAME. OVER THE FRONT OR REAR OF THE MUFFLERS YOU WILL FIND A CROSS-MEMBER OR BODY MOUNT THAT A HOLE CAN BE DRILLED FOR A 5/16" BOLT TO HOLD AN LB7 HANGER IN PLACE. ATTACH THE LB7 TO THE FRAME USING A 5/16" BOLT, GROMMET, AND NUT, AND CLAMP TO THE MUFFLER USING A 2-1/4" CLAMP.

- 5) FOR BLAZER AND JIMMY, YOU MAY NEED TO TRIM OFF FROM THE REAR OF THE #15527 EXTENSION PIPES, AND POSSIBLY OFF THE INLET OF THE LEFT AND RIGHT TAIL PIPES IF NECESSARY.
- 6) INSTALL THE LEFT (#8807L) AND RIGHT (#8806R) TO THE MUFFLERS USING A 2-1/4" CLAMP.
- 7) INSTALL THE TAIL PIPE EXTENSIONS TO THE LEFT AND RIGHT TAIL PIPES. TRIM TO YOUR DESIRED LENGTH. ABOVE THE CONNECTING POINT OF THE TAIL PIPE AND THE TAIL PIPE EXTENSION, DRILL A 5/16" HOLE IN THE FRAME. INSTALL AN LB7 HANGER USING A 5/16" X 1-1/2" BOLT, NUT, AND GROMMET AND CLAMP THE HANGER TO THE TWO PIPES. AN EXTRA BR92073 SWINGER HANGER, NUT, 5/16" X 1" BOLT, FENDER WASHER, LOCK WASHER, AND CLAMP HAVE BEEN INCLUDED FOR EACH SIDE OF THE SYSTEM. USE AS NECESSARY ON EACH SIDE.
- 8) MAKE SURE THAT ALL THE PARTS OF THE SYSTEM ARE CLEAR OF FRAME MEMBERS, ALL HOSES, SUSPENSION, AND BRAKE AND FUEL LINES. STARTING AT THE EXHAUST MANIFOLDS, TIGHTEN ALL CONNECTIONS AND NUTS. MAKE SURE ALL PARTS ARE CLEAR AND WILL NOT LEAK OR RATTLE. AFTER SEVERAL DAYS OF DRIVING RETIGHTEN ALL BOLTS.

Heartthrob exhaust systems are manufactured by Heartthrob Exhaust--Litchfield, MN

www.heartthroboxhaust.com 320-693-0222

Email us at mike@heartthroboxhaust.com with any questions.