

**# 1029000**

Cat-back 2-1/2" single kit with performance muffler, 2005-2009 Ford Mustang V6

Kit Includes:

- 3) 2-1/2" clamp
- 1) passenger side over the axle pipe--#1029023
- 1) right muffler #1028888
- 1) front extension pipe # 1029001

**DANGER WARNING:** Should the purchaser decide to install this exhaust product at home, be warned that pleasure car or light duty truck/van "bumper" jacks are intended for emergency use only. The use of frame contact jack stands in conjunction with a floor jack as main support is highly recommended to minimize accidental dropping of a vehicle while the installation proceeds.

Limitation of liability--Disclaimers: The regulation of emissions production, noise levels and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns and counties.

The manufacturer makes no warranties of merchantability, of fitness for a particular purpose, or that its products are approved for general use, or that its products comply with laws, regulations or ordinances in the states where they may be sold to the ultimate purchaser, the consumer.

The entire risk as to the conformity of this product in any such state and as to repair, should the product prove to be defective or non-conforming, is on the retail purchaser, the buyer, the ultimate consumer of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, and or repair.

The foregoing statement limits the liability of the manufacturer.

Instructions:

**NOTE: DO NOT TIGHTEN ANY BOLTS OR CLAMPS UNTIL THE LAST STEP!!**

- 1) Support the vehicle in a safe manner, using a shop hoist or frame contact jack stands on a level surface. Remove the o.e. muffler, at the clamp where the old muffler bolts to the over the axle pipe. For easiest installation, we recommend that you remove the o.e. hanger mount from the vehicle, and reinstall this hanger to the vehicle once the muffler is loosely on the extension. Also remove the o.e. front extension/over the axle pipe up to the clamp after the converter y-pipe.
- 2) Install the front extension to the converter y-pipe using a 2-1/2" clamp.
- 3) Install the inlet of the over the axle tail pipe (2-1/2" id inlet) to the front extension pipe using a 2-1/2" clamp.
- 4) Install the muffler to the over the axle pipe using a 2-1/2" clamp. Connect the wire hangers on the muffler to the o.e. mounts above.
- 5) Check for clearance of the frame, body, suspension members, and of all brake and fuel lines. When you are satisfied with how the mufflers hang, tighten the clamps.

Heartthrob exhaust systems are manufactured by Heartthrob Exhaust--Litchfield, MN

Email us at [mike@heartthrobexhaust.com](mailto:mike@heartthrobexhaust.com) with any questions. [www.heartthrobexhaust.com](http://www.heartthrobexhaust.com)  
320-693-0222

**BUILD SHEET FOR: 2-1/2" MUSTANG Cat-back V6 05-09**

**PART #'S: 1029000**

- 1) HARDWARE KIT
- 1) RIGHT MUFFLER #1028888
- 1) passenger side over the axle pipe--#1029023
- 1) front extension pipe # 1029001

INSPECTED BY: \_\_\_\_\_

DATE: \_\_\_\_\_

